

\_

Press the "+" Tempo button to speed up the tempo of the song; press the "-" Tempo button to slow the tempo.

Add different echo effects.

No Echo Concert Hall Echo Mountain Top Echo (The icon for the echo effect selected appears in the top right corner of the TV screen.)

### **EFFECTS**

Choose a cool voice effect to add fun and excitement to a song. The voice effects are activated only while you press and hold the Start button. (The icon for the effect selected lights up in the top right corner of the TV screen while active.)

Soprano raises the key of your voice.

Rass lowers the key Vibrato

adds a vibrating effect to your voice

## **SELECT KEY (Dual Purpose)**

Press the Select/Key buttons to scroll through the song list so you can

While singing, use the Select/Key buttons to raise or lower the song key. Choose the key that's just right for you!

## **DISPLAY WINDOW**

Indicates song numbers, key and tempo.

## **DUET Input Jack**

The Duet input jack on the bottom of the connector on the cord of the ekara headset allows you to connect an e-kara™ Pro Duet Headset (not included) so a friend can sing along with you! You can connect up to 10 Duet Headsets at once, allowing you to create your own singing group with all your friends!

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
  Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void All Rights Reserved. the user's authority to operate the equipment

While a song is playing, press both the "+" and "-" Tempo buttons at the same time to fast-forward through a song. It's perfect to use when you want to cut introductions and interludes or when you want to practice at the same point in a song over and over again. (There is no rewind feature.)

### Auto Power Off

The power shuts off automatically after 15 minutes of nonuse

## Low Battery Indicator

When the batteries begin to weaken and need to be replaced, the Low Battery Indicator will flash in the top left corner of the TV screen. The Indicator flashes slowly when the batteries are running low and quickly if the batteries are running out.

## NOTE:

- -To remove the cable from the TV input jack, pull the plug, not the cord
- -Do not drop, swing or strike the e-kara™ headset. -Keep the headset away from moisture and high and low temperatures. Do not use near water.

The e-kara headset won't pick up your voice.

Sing into the microphone and keep it as close to your mouth as possible.

## The power keeps going off.

When you attempt to turn the power on without inserting the cartridge first, the number "88" will flash in the Display Window, then the power will go off. Be sure to insert the cartridge first before turning the power on.

The screen may freeze if you drop e-kara™ or if it absorbs some force. Press the Reset button on the side of the headset to restart

## There is feedback.

When you place the e-kara<sup>™</sup> headset too close to the television speakers, you may get feedback. Keep the headset away from your

Look for these additional e-kara components (sold separately): E-kara™ Pro Duet Headsets allow up to 10 friends to sing along!

• E-kara™ Karaoke Cartridges feature today's hottest hits

Additional cartridges sold separately



This product is powered by XaviX technology. XaviX® is a trademark of SSD Company Limited. U.S. Patent Pending. Manufactured by Takara Co., Ltd. 2001.

Distributed by Hasbro. ®\* and/or ™\* & © 2002 Hasbro, Pawtucket, RI 02862 USA.

es Reg. U.S. Pat. & TM Office. MADE IN CHINA. PN 6159830000

TAKARA


11539

Thank you for choosing e-kara™! Please read and follow all instructions before using this product. Retain the instructions for future reference.

Video and audio input jacks are required on TV or VCR/DVD.

# e-kara™ set-up

## Includes:



e-kara™ pro headset

cable with TV input plugs

## **Requires:**

Phillips screwdriver (not included) required

for battery installation.

4 "AA" alkaline batteries (not included).

- Do not connect the e-kara™ unit to projection TVs (TVs that use projection screens instead of cathode ray tubes) because this may cause screen discoloration.
- Adult assembly is required for battery installation and product set-up.
- Input cable is not a toy. Adult set-up and supervision required.


## /!\ CAUTION: TO AVOID BATTERY LEAKAGE


- 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2. Do not mix old batteries and new batteries or alkaline, standard (carbon zinc) or use rechargeable (nickel-cadmium) batteries;
- 3. Always remove weak or dead batteries from the product.

Do not wind the cord around headset.



Using a Phillips screwdriver, remove the battery lid found in the back of the headset, Insert 4 "AA" alkaline batteries as indicated. Replace lid.





Songs provided through Newgent Inc

# e-kara™ set-up



## To use e-kara headset with starter songs:

- 1. Plug in the connectors to the video/audio jacks on TV set.
- 2. Turn on the on/off switch on e-kara Pro Headset.
- 3. The Xavix® logo, Takara® logo and e-kara™ logo will appear. Push the start button located on the main unit to view the sample three song list.
- 4. Select the song you would like to hear using the up and down arrow keys and pushing the start button to begin.


## To use e-kara headset with song cartridge:

Insert the e-kara Karaoke cartridge into the cartridge slot until vou hear a click. Be sure the label side faces out and can be read when the cartridge is inserted into the toy. Insert the cartridge until the bottom of the label becomes level with the slot.





Connect the translucent cable plug to the Main Unit input jack on the bottom of the e-kara™ headset. Be sure to insert the plug all the way into the jack.






Connect the black cord's plug from the headset directly into the bottom of the e-kara Main Unit. Be sure to insert the plug all the way into the jack.





Connect the colored cable plugs to the input jacks on your TV set or your VCR/DVD. Match the color of the plug to the color of the input jack (white to white, red to red, yellow to yellow). The yellow plug connects to the "Video In" jack and the white and red plugs connect to the left and right "Audio" jacks for stereo sound. (You can connect just the yellow and white plugs for mono sound.) (Refer to your TV or VCR/DVD instructions for more information.)




Now you're ready to Karaoke with e-kara™!

# sing with e-kara™




Turn on your TV set (and VCR/DVD) and switch the TV to Video/Aux. mode. (Refer to your TV and VCR/DVD instructions for more information.)



**[2**]


Press the On/Off button on the side of the headset to turn e-kara™ on.



[3]


When you see the title screen on the TV, press the Select/Key arrow buttons to select either stereo or mono, then press the Start button.

- (With red, white and yellow plugs) connected, choose stereo.)
- · (With only white and yellow plugs connected, choose mono.)



4

Use the Select/Key arrow buttons to choose a song from the song selection menu on the TV. Press the Start button to play the song and see lyrics on the TV. It's time to sing!



Move up or down

To adjust the balance between your voice and the music, first adjust the volume of the music. To do this, press the "+" and "-" Volume buttons on the headset to turn the music up or down. Then, adjust the volume of both the headset and the music together by adjusting the volume on your TV. To stop the song that's playing, press the Cancel button, which will bring you back to the song selection menu.

[6]

How to e-kara with a friend:

 Plug the duet headset cord into the bottom of the connector located on the cord of the person you are singing along with.

