

TJ Bearytales™

PLAYSKOOL

SHARING the GIFT of STORY™

Thank you for purchasing this PLAYSKOOL toy!

Includes "microphone," story cartridge,
and SHARE & TELL storybook


GETTING STARTED:

Your T.J. BEARYTALES "microphone" works in two ways:

1. BEFORE you turn T.J. BEARYTALES on, slide the "microphone" into his left paw. While the bear tells the story, the "microphone" will light up each time he sings.


2. Your child can also remove the "microphone" from the bear's paw and play with it separately.

- Press the button to activate the lights.
- Press the button again to activate a different light sequence.



TO INSTALL BATTERIES:

Using a Phillips/cross head screwdriver (not included), loosen screw in battery compartment cover. Remove cover. Insert 3 x 1.5V "AAA" or R03 batteries. Alkaline batteries recommended. Replace door, and tighten screw with screwdriver. See diagrams for polarity.



 **x3** 1.5V AAA or R03 size
NOT INCLUDED
BATTERIES REQUIRED

Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to insert batteries.



CAUTION: TO AVOID BATTERY LEAKAGE

1. As with all small batteries, the batteries used in this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor. In other countries, have the doctor call your local poison control center.
2. Make sure the batteries are inserted correctly and always follow the toy and battery manufacturers' instructions.
3. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.



CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
8. As with all small items, these batteries should be kept away from children. If swallowed, seek medical attention immediately.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.



Products and colors may vary.
© 2006 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks
51674

P/N 6627530001