

This toy simulates the function of real workshop tools. Please caution your child about the hazards of real workshop tools.

### FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

AGES 2+  
08991/08132

# PLAYSKOOL



## Sawyer the Saw™



Thank you for choosing this PLAYSKOOL toy!

Visit us at  
[playskool.com](http://playskool.com)



© 2006 Hasbro. All Rights Reserved.  
TM & ® denote U.S. Trademarks  
08991/08132 P/N 6599740000

**NOTE:** Adult should remove  
and discard wire ties.


**x3 BATTERIES INCLUDED**  
Replace with 3 x 1.5V "AA" or LR6 size alkaline batteries. Phillips/cross head screwdriver (not included) needed to replace batteries.

## PLAY FEATURES

Pretend to build with this animated electronic buddy!


Simply press the button on the handle to get the blade spinning and activate saw sounds and silly phrases. Each time you press the button, the SAWYER THE SAW toy will say a phrase.

When you press the button AND push the SAWYER THE SAW toy along a surface, you activate cutting sounds and more silly phrases!



## TO REPLACE BATTERIES

Using a Phillips/cross head screwdriver (not included), loosen screw in battery compartment cover. Remove cover. Remove and discard batteries. Insert 3 x 1.5v "AA" or LR6 size alkaline batteries. Replace door, and tighten screw with screwdriver. See diagrams for polarity.



### ! CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.

### IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.

Batteries should be replaced by an adult.

### ! CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.