




OVER 18M-4Y




NOTE TO CONSUMER:

Before playing with LOL Elmo, replace demo batteries with fresh 4 x 1.5V AA alkaline batteries. This toy is packaged in TRY ME mode. When you bring the toy home, activate its full range of features by moving its TRY ME/OFF/ON switch to the ON position, then follow instructions for PLAY mode.




INCLUDES:
Elmo and Dorothy's fishbowl squeaker




TO PLAY


There are so many ways to make Elmo laugh out loud! Turn the TRY ME/OFF/ON switch to the ON position, then:



Tickle his tummy!



Tickle his feet!



Squeeze Dorothy's fishbowl or make a silly sound!

NOTE:

To activate Elmo using Dorothy's fishbowl squeaker, hold it approximately 6 inches from Elmo's tummy, then give it a squeeze!

NOTE: The more Elmo is tickled, the more he'll laugh and wiggle!

 **x4 ALKALINE BATTERIES REQUIRED**
1.5VAA DEMO BATTERIES INCLUDED



IMPORTANT! PLEASE READ INSTRUCTIONS COMPLETELY BEFORE USING TOY.

JOKE MODE:

To hear LOL Elmo tell funny jokes, just press and hold either foot for 3 seconds! Each time his foot is pressed, he will tell another joke. If his foot isn't pressed for 5 seconds, Elmo will ask you to press one of his feet so he can share another joke. If either foot isn't pressed for another 5 seconds, LOL Elmo will return to his regular PLAY MODE. To return to PLAY MODE anytime, press either of Elmo's feet for 3 seconds.

SLEEP MODE:

After a little while of inactivity, LOL Elmo will prompt to keep playing. After no response, Elmo will enter sleep mode in 15-20 seconds. To reactivate LOL Elmo, just press either of his feet to get the giggling fun started again!


TROUBLESHOOTING:

If you are having trouble making LOL Elmo laugh out loud, try these easy steps:

1. Make sure to move the TRY ME/OFF/ON switch from the TRY ME to the ON position.
2. If you are still having trouble, turn the switch to the OFF position, wait at least 2 seconds, then turn it to the ON position again.
3. If LOL Elmo still doesn't laugh, make sounds or roll back and forth, it may be time to change the batteries.

TO REPLACE BATTERIES:

Replace demo batteries with alkaline batteries. Use a Phillips/cross head screwdriver (not included) to loosen screw in battery compartment cover located on Elmo's back (screw remains attached to cover). Remove cover. Remove and discard old batteries. Replace with fresh 4 x 1.5V AA size alkaline batteries. Replace cover and tighten screw.



IMPORTANT: BATTERY INFORMATION



CAUTION:

1. TO AVOID BATTERY LEAKAGE

- a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- c. Remove exhausted or dead batteries from the product.
- d. Remove batteries if product is not to be played with for a long time.
- e. Do not short-circuit the supply terminals.

f. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**

2. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Questions? Call 1-800-327-8264



Product and colors may vary. Retain these instructions for future reference.

** and/or TM* & © 2012 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved. TM & * denote U.S. Trademarks.

Sesame Street* and associated characters, trademarks and design elements are owned and licensed by Sesame Workshop. © 2012 Sesame Workshop. All Rights Reserved.



A1500

PN 7296100000