

AGES 4+
77628

⚠ CAUTION: TO AVOID BATTERY LEAKAGE

1. As with all small batteries, the batteries used in this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect. In other countries, have the doctor call your local poison control center.
2. Make sure the batteries are inserted correctly and always follow the toy and battery manufacturer's instructions;
3. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.

⚠ CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
8. As with all small items, these batteries should be kept away from children. If swallowed, seek medical attention immediately.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.




MONKEY SHOUT

SPR4-77

HYPERFORCE LED!

Press down on head for lights and battle cries, and to open mouth.


Snap on battle hands.



Monkey Shout Figures

TO INSERT BATTERIES:

1. Use a Phillips/cross head screwdriver to loosen the screw in the battery cover.
2. Remove battery cover, and insert batteries as shown.
3. Replace battery cover and tighten screw.



Batteries included. Replace with 3 x 1.5V "R-76" or LR44 size alkaline batteries. Phillips/cross head screwdriver (not included) needed to replace batteries. Class 1 LED product.



Not suitable for children under 3 years because of small parts - choking hazard.

Product and colors may vary. TM & © Disney. TM & © ABC Family Worldwide. All Rights Reserved. ® and/or TM* & © 2005 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks. P/N 6521790000