

BOGA[™] BATTLE MASTERS^{™*} FIGURE

BUTTON

INCLUDES FIGURE AND QUICK-START GUIDE.

MOVE BOGA FIGURE TO SIDE OF ATTACKTIX BATTLE FIGURE. PRESS BUTTON - TAIL SWINGS TO KNOCK OVER FIGURE.

(Figure not included.)



TWO TARGET SPOTS -OPPONENTS HIT THEM TO KNOCK FIGURE OVER.

NOTE: Must hit both target spots to knock figure over.



TO RESET, RAISE FIGURE UNTIL IT CLICKS IN PLACE.



Some poses may require additional support.
Product and colors may vary.

© 2005 Lucasfilm Ltd. & ® or TM where indicated. All rights reserved.
Used under authorization.

®* and/or TM* & © 2005 Hasbro. All Rights Reserved.

© denotes Reg. U.S. Pat. & TM Office.

Patents Pending

attacktix.com

P/N 6425970000