


Barney's™ Fun Splash Sprinkler Instructions

Ages 2 & Up




Product and colors may vary

**Includes: Barney™ figure and assembled sprinkler base.
Adult supervision recommended.**



1. Insert sprinkler post into hole in Barney™ figure as shown.



2. Fit the end of any standard garden hose into sprinkler nozzle. Turn sprinkler nozzle counterclockwise as shown to tighten. Turn on water to activate sprinkler.

HELPFUL HINT:

1) Your water pressure may vary depending on your location. For best results, turn water on low and adjust pressure to desired height of sprinkler.

CAUTION: Water that is left inside garden hose for an extended period of time in direct sunlight can become very hot. After each use, we advise you to drain sprinkler and the garden hose, and store them in a cool shady area.

© 1993 The Lyons Group. "Barney™" and "Baby Bop™" are trademarks of The Lyons Group. Distributed by Kid Dimension Inc., a subsidiary of Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.

MADE IN CHINA

29950 P/N 44464100