



Welcome to Cranium® Giggle Gear™

Mega Mask

Create hilarious faces and change your voice!

GET STARTED

1 Assemble the Base

- Take out the mask-making pieces, mask base, microphone, and speaker.
- Ask a grown-up to help you securely attach the microphone to the mask base.
- Make sure the microphone cord is plugged in to the speaker.



2 Make Your Mask

- Choose any parts you want to create your unique mask.
- Attach the parts to the mask base. (Be sure to attach the parts *before* putting on your mask.) Save the mouth for last.
- Now it's time to choose a mouth to go with your mask. Each mouth will change your voice in a different way! Attach the mouth you've chosen to the microphone.



3 Get Ready to Play!

- Put on your mask and adjust the strap to fit comfortably.
- Adjust the microphone so it's near your mouth.
- Clip the speaker to your pocket or waistband.
- Turn the speaker dial to ON. Keep turning the dial to increase the volume.
- Try saying something with your new voice. Have fun!



When you've finished, take off your mask and turn the speaker dial to OFF—that'll make your batteries last longer.

To change your mask, take the mask off and choose new parts!



TROUBLESHOOTING

Are you having trouble with your Mega Mask? Try these tips!

If...

Your Mega Mask isn't loud enough...

Your voice isn't coming through the speaker...

Your speaker won't turn on...

The sound is breaking up...

Try this!

Turn the dial on the speaker to increase the volume.

**Check the connection between the mouth part you've chosen and the microphone.
Check to make sure the cord is plugged in to the speaker.**

**Turn the speaker dial in either direction.
Install one new 9-volt battery.**

**Make sure the microphone is near your mouth.
Install one new 9-volt battery.**

If you've tried all these steps and you're still having trouble...

In the U.S., go to cranium.com/support
Outside the U.S., go to cranium.com/worldwidesupport

We value your input and we'll do our best to help!

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules and EMC regulations. Conforms to the requirements of EN 50088. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.



WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

© 2006 CRANIUM, INC. ALL RIGHTS RESERVED. CRANIUM CHARACTER ILLUSTRATIONS © 1998-2004 BASEMAN™ THE FOLLOWING ARE TRADEMARKS OR REGISTERED TRADEMARKS OF CRANIUM, INC. IN THE U.S. AND/OR OTHER JURISDICTIONS: CRANIUM, CREATIVE CAT, DATA HEAD, EVERYONE SHINES, GIGGLE GEAR, STAR PERFORMER, WORD WORM, THE CRANIUM LOGO, AND THE BRAIN LOGO. WE PACK EVERY CRANIUM TOY WITH A VARIETY OF OUTRAGEOUS ACTIVITIES. IT'S UP TO YOU TO USE CAUTION, PLAY IT SMART, AND HAVE FUN.

CHANGING THE BATTERY

Need to change the battery? Ask an adult to get a 9-volt battery and follow these instructions:

1. Turn your Mega Mask speaker over and unscrew the battery cover.
2. Insert the battery as indicated.
3. Replace the battery cover and tighten the screw.

BATTERY SAFETY:

- Do not put the battery in backwards. Positive (+) and negative (-) ends must be inserted in the correct directions following the polarity (+/-) diagram in the battery compartment.
- Only batteries of the same or equivalent type as recommended are to be used.
- Rechargeable batteries must be removed before recharging.
- Rechargeable batteries must be recharged by an adult only.
- Batteries must be installed and removed by an adult only.
- Remove exhausted batteries and dispose of them properly.
- Do not try to recharge non-rechargeable batteries.
- The supply terminal is not to be short-circuited.



**WARNING: TO AVOID
BATTERY LEAKAGE**
Please follow these battery usage instructions. Failure to follow these instructions can result in battery acid leakage that may cause burns, personal injury, and property damage.

For even more fun, visit cranium.com!