



Welcome to Cranium Giggle Gear

Robo Talkies

Talk with friends and send robo sounds!

GET STARTED

1 Assemble the Talkies

- Take out the click-in parts, headsets, and headbands.
- Give a headset and a headband to a friend.
- Install a 9-volt battery into one of the headsets.
- Attach the headsets to the headbands.
- Choose some click-in parts and attach them to the headbands.
- Put on the Robo Talkies, then adjust the microphone in front of your mouth.



2 Get Ready to Play

- To turn on the Talkies, slide down the silver switch on the headset.
- Press the silver button on the headset to talk to your friend.
- Release the silver button to hear your friend speak.
- Press the silver and red buttons at the same time to send robo sounds to your friend.
- Now go and make someone giggle. Have fun!



To change the headbands, take them off and choose new click-in parts. You can use any Giggle Gear mix-and-match pieces to create even more hilarious combinations. You can also attach a Talkies headset to a Mega Mask base!

For even more fun, visit cranium.com!

TROUBLESHOOTING

Are you having trouble with your Robo Talkies?

If one of your Robo Talkies headsets won't turn on or send sounds, or the sound is garbled, try installing a new 9-volt battery.

If you've tried this step and you're still having trouble...

In the U.S., go to cranium.com/support or call 1-877-CRANIUM

Outside the U.S., go to cranium.com/worldwidesupport

We value your input and we'll do our best to help!

WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Model no. 303033100. Canada 310. Carrier frequency: 49.860 MHz, field strength: 60.0 dBuV/m at 3 m. This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310. Ce dispositif de radiocommunication rencontre toutes les exigences de la norme CNR-310 d'Industrie Canada. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CHANGING THE BATTERY

Need to change the battery? Ask an adult to get a 9-volt battery and follow these instructions. (9-volt batteries can usually be found in the photo and electronics sections of major retailers, pharmacies, and supermarkets.)

1. Turn your headset over and unscrew the battery cover.
2. Insert the battery as indicated.
3. Replace the battery cover and tighten the screw.

BATTERY SAFETY

- Do not put the battery in backwards. Positive (+) and negative (-) ends must be inserted in the correct directions following the polarity (+/-) diagram in the battery compartment.
- Only batteries of the same or equivalent type as recommended are to be used.
- Rechargeable batteries must be removed before recharging.
- Rechargeable batteries must be recharged by an adult only.
- Batteries must be installed and removed by an adult only.
- Remove exhausted batteries and dispose of them properly.
- Do not try to recharge non-rechargeable batteries.
- The supply terminal is not to be short-circuited.



WARNING: TO AVOID BATTERY LEAKAGE

Please follow these battery usage instructions. Failure to follow these instructions can result in battery acid leakage that may cause burns, personal injury, and property damage.

Activity Guide

- Play a game of robot tag.
- Hide and give a friend clues to find you.
- Take turns telling robot-alien stories.
- Talk like a robot at the dinner table.
- Tell robot knock-knock jokes to a friend.
- Make up your own robot words.



WARNING:
CHOKING HAZARD — Small parts.
Not for children under 3 years.

© 2007 CRANIUM, INC. ALL RIGHTS RESERVED. CRANIUM CHARACTER ILLUSTRATIONS © 1998, 2001 **BASEMAN**™. THE FOLLOWING ARE TRADEMARKS OR REGISTERED TRADEMARKS OF CRANIUM, INC. IN THE U.S. AND/OR OTHER JURISDICTIONS: CRANIUM, CREATIVE CAT, DATA HEAD, EVERYONE SHINES, GIGGLE GEAR, STAR PERFORMER, WORD WORM, THE CRANIUM LOGO, AND THE BRAIN LOGO. WE PACK EVERY CRANIUM TOY WITH A VARIETY OF OUTRAGEOUS ACTIVITIES. IT'S UP TO YOU TO USE CAUTION, PLAY IT SMART, AND HAVE FUN.

For even more fun, visit cranium.com!