



Welcome to Cranium Wonder Works
Talking Picture Book
 Record your own storybook!

GET STARTED

1 Open the book and start drawing. Use as many of the reusable cling stickers and colored pens as you like. You can use one page, two pages, or the whole book. It's up to you!



2 When you're ready, move the purple sliding switch to **RECORD**.



3 Now add descriptions or sound effects to your drawings! **PRESS** and **HOLD** the **PURPLE** button marked **1**, wait for the beep, then add your voice or sound effects to page **1**. Do the same for pages **2**, **3**, and **4**. Don't forget to wait for the beep!

4 When you've finished recording, move the purple sliding switch to **PLAY**. Press the button marked **1** (or **2**, **3**, or **4**) to hear your voice. You can share your special creation with your family and friends!



5 Ready for more fun? Erase your pictures and make a new masterpiece!



★ Get outrageous ideas for your next creation. Insert an activity card into the slot, wind up the spinner, and let it go!



TROUBLESHOOTING

Are you having trouble with your Talking Picture Book? Try these tips!

If your Talking Picture Book...

Sounds garbled...

Try this!

Install four new AAA batteries.

Won't play...

Make sure the switch is set to **PLAY**. Install four new AAA batteries.

Won't record...

Make sure the switch is set to **RECORD**. Hold down the button while you record. Install four new AAA batteries.

Stops in the middle of playing...

Install four new AAA batteries.

If you've tried all these steps and you're still having trouble...

In the U.S., go to cranium.com/support or call 1-877-CRANIUM
 Outside the U.S., go to cranium.com/worldwidesupport

We value your input and we'll do our best to help!

★ **HELPFUL HINT:**

If your clings don't stick to the cling sheet, try cleaning them and placing them directly onto the white background of the sheet.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules and EMC regulations. Conforms to the requirements of EN 50088. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CHANGING THE BATTERIES

Your Talking Picture Book needs four AAA batteries. Follow these steps to install the batteries. Batteries must be installed and removed by an adult.

1. Turn your Talking Picture Book over and unscrew the battery cover.
2. Insert the batteries as indicated.
3. Replace the battery cover and tighten the screw.

BATTERY SAFETY:

- Do not put the batteries in backwards. Positive (+) and negative (-) ends must be inserted in the correct directions following the polarity (+/-) diagram in the battery compartment.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not mix old and new batteries.
- Rechargeable batteries must be removed before recharging.
- Rechargeable batteries must be recharged by an adult only.
- Batteries must be installed and removed by an adult only.
- Remove exhausted batteries and dispose of properly.
- Do not try to recharge non-rechargeable batteries.
- The supply terminals are not to be short-circuited.



WARNING: TO AVOID BATTERY LEAKAGE
 Please follow these battery usage instructions. Failure to follow these instructions can result in battery acid leakage that may cause burns, personal injury, and property damage.

WARNING: CHOKING HAZARD
 Small parts. Not for children under 3 years.



Make more drawings!
 Use your Talking Picture Book stickers and pens with Cranium Wonder Works Picture Studio.

For even more fun, visit cranium.com!



Welcome to Cranium® Wonder Works™
Talking Picture Book
 Record your own storybook!



It would take 20 AAA batteries to power my jet pack.



Empty pages and a handful of pens... it's an artist's dream!

Learn more



I can't wait to hear your stupendous story.

Get started!



It's your chance to shine!

© 2008 CRANIUM, INC. ALL RIGHTS RESERVED. CRANIUM CHARACTER ILLUSTRATIONS © 1988, 2001 B&S/MW. THE FOLLOWING ARE TRADEMARKS OR REGISTERED TRADEMARKS OF CRANIUM, INC. IN THE U.S. AND/OR OTHER JURISDICTIONS: CRANIUM, CRANIUM WONDER WORKS, CREATIVE CAT, DATA OF OUTRAGEOUS ACTIVITIES, IT'S UP TO YOU TO USE CAUTION, PLAY IT SMART AND HAVE FUN.

W008g5117