

7. If you want the showcase to stand up on a flat surface, turn the showcase around and take the two easel pieces marked E and F. As you are looking at the back of the showcase, the easel piece marked E goes into the slot on your left, and F goes into the slot on your right. When you attach the pieces, be sure to hook the bottom of the easel piece first, then push it up into the tabs.



8. If you want to hang the showcase on a wall, skip step #7 and do not attach the easel pieces. There is a nail hole on the back of the showcase.








Not suitable for children under 3 years because of small parts - choking hazard.

We will be happy to hear your questions or comments about this product. US consumers please write to: Hasbro Games, Consumer Affairs Dept., P.O. Box 200, Pawtucket, RI 02862. Tel: 888-836-7025 (toll free). Canadian consumers please write to: Hasbro Canada Corporation, 2350 de la Province, Longueuil, QC Canada, J4G 1G2.

Products and colors may vary.
© 2007 Hasbro. All Rights Reserved.
TM & @ denote U.S. Trademarks.
1014407400





## GETTING STARTED ...

Disassemble the enclosed parts sheet to produce these pieces:


- 1 BACK PANEL
- 2 FRAME PIECES
- 4 HORIZONTAL BRACES
- 2 LONG VERTICAL BRACES

- 2 SHORT VERTICAL BRACES
- 4 FRONT PIECES
- 2 EASEL PIECES


## ASSEMBLY. ...

1. Place the back panel on a flat surface, with the pictures of the rooms facing up.

2. Take the two (2) frame pieces and align them to the back panel. Push the tabs into the slots.




3. Take the four (4) horizontal braces and align each of them to the back panel. Push the tabs of each lettered brace (A, B, C and D) into the slots. A goes into the top slot, B goes into the second, and so forth.




4. Take the two (2) long vertical braces and align them to the two center columns of the showcase.

Push the tabs into the slots



5. Take the two (2) short vertical braces and align them to the two outer columns of the showcase. Push the tabs into the slots.



 Take the four (4) front pieces of the showcase, and, with the decorated side facing up, align each piece to the vertical and horizontal braces. Push the tabs into the slots.

