

TO INSTALL NEW BATTERIES

1. Open back seam to locate battery compartment. With Phillips screwdriver, loosen screw in battery compartment door. Remove door (screw remains attached to door).
2. Discard old batteries. Insert 2 fresh "AA" alkaline batteries into compartment as shown. Replace door and tighten screw.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3) Always remove weak or dead batteries from the product.

www.bobthebuilder.com



© HIT Entertainment PLC and Keith Chapman 2001
*®, *TM & © 2001 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
6925/6809 Asst.
6932/6809 Asst.
P/N 6134140000


PLAYSKOOL.COM
FOR NEW PRODUCTS AND OFFERS

NOTE: Adult should remove and discard plastic fasteners.
SURFACE WASHABLE ONLY.
FILLING: ALL NEW MATERIALS: 100% POLYESTER FIBER, PLASTIC STIFFENER
REG. NO. PA - 282

AGES 2+

6925/6809 Asst.

6932/6809 Asst.



**Bob the Builder™
Talking Plush**

**Wendy™ Talking
Plush**



**Thank you for choosing this huggable BOB
THE BUILDER friend!**

**Includes 2 "AA" batteries. Phillips screwdriver (not
included) required for battery replacement.**

