






x2
































## "FLOTATION" DEVICE!














## EMERGENGY RESCUE COPUER



00000000000

000000000



000000000000000

0000000000

0000000000

P/N 6255520001



Product and colors may vary. © 2003 Hasbro. All Rights Reserved. \*denotes Reg. U.S. Pat. & TM Office. Hasbro Canada, Longueuil, QC, Canada J4G 1G2.



Questions? Call: 1-800-327-8264



Not suitable for children under 36 months due to small parts, choking hazard.



Please keep company details for future reference.
Distributed in the United Kingdom by Hasbro UK Ltd., Caswell Way, Newport, Gwent NP9 0YH.
Distributed in Australia by Hasbro Australia Ltd., 570 Blaxland Road, Eastwood, NSW 2122, Australia. Tel: (02) 9874-0999.
Distributed in New Zealand by Hasbro New Zealand Ltd., Albany Highways, Auckland, PO Box 100 940. North Shore Mail Centre, Auckland, New Zealand 1333. Tel: (649) 415-9916.

000000000000000000000000000000