


## To Fold Playmat:

With mat facing up, slide strap through all 3 buttonholes. Then, put button through buttonhole in strap. Now the playmat is closed!



To Wash Mat: Place in pillow case and tie end closed. Machine wash separately--gentle cycle, cold water, mild detergent, no bleach. Tumble dry promptly in pillow case, low heat setting.

To Wash Barney Figure: Machine wash--gentle cycle, cold water, mild detergent, no bleach. Tumble dry on low heat setting.

Product and colors may vary.

MADE IN CHINA. SCRATCH TICKET MADE IN U.S.A.

P/N 47164100

<sup>© 1996</sup> The Lyons Group. All Rights Reserved. The Barney, BJ and Baby Bop names and characters and the overlapping dino spots logo are trademarks of The Lyons Group.

<sup>© 1996</sup> Universal Studios Florida. All Rights Reserved.

<sup>© 1996</sup> Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.

<sup>®</sup> denotes Reg. U.S. Pat. & TM Office