

6478




# BATMAN® FOREVER BAT-SIGNAL™ BLASTER


## OPERATING INSTRUCTIONS

Battery and Bulb Installation on reverse side


**1** Load dart all the way into the barrel.



**2** Pull back handle until it locks in place.



**3** Squeeze trigger gently (halfway) to display Bat-Signal™. Squeeze trigger completely to fire dart.




Slide cylinder back and forth to adjust focus of Bat-Signal™.

**Skinner**  
© and © 1995 TOYKA CORPORATION  
a subsidiary of Hasbro, Inc., Pawtucket, Rhode Island 02862. All Rights Reserved.  
BATMAN and all related elements are the property of DC Comics. TM and © 1995. All Rights Reserved.  
MADE IN CHINA  
51962901


**CAUTION:** To avoid battery leakage, (1) Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instructions. (2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable batteries. (3) Always remove exhausted or dead batteries from the product.

**4** An adult should use a screw-driver to pry open battery door to install or replace 2xAA alkaline batteries.



### BULB REPLACEMENT-ADULT ASSISTANCE RECOMMENDED


**A** Loosen only one screw on side of the barrel.




**B** Slide out lens housing.




**C** Remove bulb holder.




**D** Remove and replace bulb with #2222 bulb.



**E** Slide new bulb into bulb holder and insert holder back into lens housing.



**F** Replace lens housing.



(Bulb may need to be rotated in holder to improve focus)