

# BATMAN™

## *The Animated Series*

### **WALKIE TALKIE INSTRUCTIONS**

**AGES: 5 & UP**

#### **TO INSERT BATTERIES:**

1. Remove battery compartment door.
2. Insert one 9-volt alkaline battery into battery compartment as shown.
3. Replace battery compartment door.

#### **TO OPERATE WALKIE TALKIES:**

1. Turn the On/Off and Volume Control dial to the "On" position.
2. Press the Transmit button to send messages. Speak clearly in a normal voice, holding the walkie talkie about 4" from your mouth.
3. Release the Transmit button to receive messages.
4. Hold the antenna in a vertical position for the best transmission and reception.

#### **TO USE MORSE CODE FUNCTION:**

1. To transmit a signal, turn the On/Off and Volume Control dial to the "On" position.
2. Press the Transmit button and **AT THE SAME TIME** press the Morse Code button to send signals to the other walkie talkie.
3. To receive a signal, release the Transmit and Morse Code buttons, and adjust the Volume Control dial to the desired listening level.

#### **CAUTION: TO AVOID BATTERY LEAKAGE:**

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions.
2. Never mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Always remove exhausted or dead batteries from the product.
4. Remove batteries if product is stored for a long period of time.
5. Alkaline batteries recommended.

**WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.**

BATMAN and all related elements are the property of DC Comics Inc. TM & © 1994 DC Comics. All Rights Reserved. Distributed by Kid Dimension, Inc., a subsidiary of Hasbro, Inc., Pawtucket, RI 02862 USA. © 1994 Kid Dimension, Inc. ® denotes Reg. U.S. Pat. & TM Office. **MADE IN CHINA.**