

Includes unassembled BEYBLADE top, launcher, and ripcord.
Assembly required. Phillips screwdriver needed (not included).


⚠ WARNING: Do not use BEYBLADE tops or Beystadium on tables or other elevated surfaces.

BEYBLADE tops/Beystadium are intended to be used on the floor. Do not lean over the stadium when BEYBLADE tops are in play. BEYBLADE tops may unexpectedly fly off surface and cause eye or facial injury.

PARTS:

Runner Frame Parts, Blade Base, Launcher, Ripcord

- Before assembly and playing, please read instructions. Please keep these instructions for future reference.
- When removing parts from runner frame, ask an adult to help you trim off any excess plastic using scissors or other suitable tool.
- The frame is numbered. Please follow the numbers carefully and make sure you are assembling the right parts.
- Discard plastic bags immediately.




BEYSTADIUM sold separately.


BUILD:

1 Peel and apply sticker as shown.

Label




2 Attach spin gear (3) and gear top (2) to Blade Base with the screw.




Blade Base

Note: Make sure screw is completely attached.



Place Weight Disk (4) on Blade Base.



Attach Bit Chip on Attack Ring.




Attach Attack Ring to base, aligning tabs on ring with grooves on gear. Turn Attack Ring LEFT until it locks onto spin gear. (To remove ring from base, turn ring to the right.)

LEFT TO LOCK









Your BEYBLADE top is now ready for battle!

LAUNCH:



NOTE: Use left-spin launchers for Left Spin Gears; use right-spin launchers for Right Spin Gears.





CUSTOMIZE FOR EACH BATTLE!

WHAT IS CUSTOMIZING?

Customizing is taking parts from different BEYBLADE tops and putting them together to create a new top. Why customize? Because you can change how your top will perform in battle. By switching parts, you can create a top that will perform a certain way. For example, if your opponent has an Attack Type top, you may want to change your top's parts to make it a Defense Type top, to help withstand your opponent's attacks.

Learn all the different types of Attack Rings, Weight Disks and Spin Gears that are available and that you have in your collection. Look at the star chart on the packages to see the strengths of each top's parts and check out the website beyblade.hasbro.com for more information!

TRIPLE SHOT You and your opponent each battle 3 BEYBLADE tops for triple the action!



Product and colors may ©* and/or TM* & © 2011 Manufactured under license ©HUDSON SOFT/TAKAR TM & © ABC Family Wo