

Driaer S™

HIGH PERFORMANCE TOPS

Defense Type

Includes unassembled BEYBLADE top, launcher, and ripcord. Assembly required. No tools needed.

⚠ WARNING: Do not use BEYBLADE tops or BEYSTADIUM™ on tables or other elevated surfaces.


BEYBLADE tops/BEYSTADIUM are intended to be used on the floor. Do not lean over the stadium when BEYBLADE tops are in play. BEYBLADE tops may bounce up and hit eye or face.

- Before assembly and playing, please read instructions. Please keep these instructions for future reference.
- When removing parts from runner frame, ask an adult to help you trim off any excess plastic using scissors or other suitable tool.
- · The frame is numbered. Please follow the numbers carefully and make sure you are assembling the right parts.
- · Discard plastic bags immediately.

PARTS:

Runner Parts, Weight Disk, Blade Base, Attack Ring, Metal Change Axis. Metal Weight Gear, Labels.


Note: Bit Chip with holes/ triangle on one side can be used with BEYBLADE Electronic Launcher (sold separately).



BEYSTADIUM sold separately.

3


BUILD:



Snap both halves of 3 around the Metal Weight Gear. Make sure that the Metal Weight Gear fits into the grooves.



Peel and apply stickers as shown.



Insert the Metal Change Axis as shown.







Insert Attachments 2 into Blade Base until the tips are just past the knobs. Do not insert Attachments all the way in at this time

Place Right Spin Gear into Blade Base





Snap Attachments 2 all the way into Blade Base to secure Right Spin Gear.

8

Place Weight Disk on Blade Base.



Attach Bit Chip 1 to Attack Ring.



10




Place Attack Ring on Blade Base. aligning tabs on ring with grooves on Right Spin Gear. Turn ring left until it locks onto spin gear. To remove ring from gear, turn

















CUSTOMIZE FOR EACH BATTLE!

WHAT IS

Customizing is taking parts from different BEYBLADE tops and putting them together to create a new top. Why customize? Because you can change how your top will perform in battle. By switching parts, you can create a top that will perform a certain way. For example, if your opponent has an Attack Type top, you may want to change your top's parts to make it a Defense Type top, to help withstand your opponent's attacks.

Learn all the different types of Attack Rings, Weight Disks and Spin Gears that are available and that you have in your collection. Look at the star chart on the packages to see the strengths of each top's parts and check out the website beyblade.hasbro.com for more information!

TRIPLE SHOT You and your opponent each battle 3 BEYBLADE tops for triple the action!





Round 1
Round 2
Round 3




To start the game, players launch their first BEYBLADE top.



Round 1
Round 2
Round 3



The player who wins two out of three rounds is the winner!











MADE IN (