

Kid Dragoon"

HIGH PERFORMANCE TOPS METAL MASTER SERIES ™

Attack Type

 $Includes\ unassembled\ BEYBLADE\ top, launcher, and\ ripcord.$ Assembly required. No tools needed.


WARNING: Do not use BEYBLADE tops or Beystadium" on tables or other elevated surfaces.

BEYBLADE tops/BEYSTADIUM are intended to be used on the floor. Do not lean over the stadium when BEYBLADE tops are in play. BEYBLADE tops may bounce up and hit eye or face.

- Before assembly and playing, please read instructions. Please keep these instructions for future reference.
- When removing parts from runner frame, ask an adult to help you trim off any excess plastic using scissors or other suitable tool.
- · The frame is numbered. Please follow the numbers carefully and make sure you are assembling the right parts.
- · Discard plastic bags immediately.


PARTS:

Runner Frame Parts, Blade Base, Attack Ring, Metal Weight Gear, Launcher and Ripcord.



BEYSTADIUM sold separately.


BUILD:



Place Metal Weight Gear on 6 gear.




Snap both halves of @ Right are in grooves




NOTE! The Bit Chip sticker on the large label sheet must be applied to the Bit Chip (1) that has the holes/triangle on one side. Apply stickers to smooth sides of Bit Chips.




Insert Attachments into Blade Base until the tips are just past the knobs. Do not insert attachments all the way in at this time.



Place Right Spin Gear into Blade Base.



Snap Attachments all the way into Blade Base to secure Right Spin Gear




Place 4 Weight Disk on Blade Base.



Attach Bit Chip to Attack Ring



Attach Attack Ring to base, aligning tabs on ring with grooves on gear. Turn ring LEFT until it locks onto spin gear. (To remove ring from gear, turn ring right.)





LAUNCH:




B

Insert posts on launcher into openings in BEYBLADE top, as

shown


Hold lower half of launcher and rotate BEYBLADE top left to lock it in place.



battle!

FEATURES:


spin launchers for Right Spin Gears








Removable Right Spin Gear is interchangeable with other Spin Ge increase your customizing options for additional battle strategies.





Attack Ring has three wings for balance-battering attacks!

CUSTOMIZE FOR EACH BATTLE!

Customizing is taking parts from different BEYBLADE tops and putting them together to create a new top. Why customize? Because you can change how your top will perform in battle. By switching parts, you can create a top that will perform a certain way. For example, if your opponent has an Attack Type top, you may want to change your top's parts to make it a Defense Type top, to help withstand your opponent's attacks.

Learn all the different types of Attack Rings, Weight Disks and Spin Gears that are available and that you have in your collection. Look at the star chart on the packages to see the strengths of each top's parts and check out the website beyblade.hasbro.com for more information!

TRIPLE SHOT You and your opponent each battle 3 BEYBLADE tops for triple the action!



Decide the play order of your BEYBLADE tops

Round 1 Round 2 Round 3 Eus

To start the game, players launch their first BEYBLADE top.



▶Round 1 ▶Round 2 Round 3

The player who wins two out of three rounds is the winner!













Product and colors may v ®* and/or TM* & © 2003 © HUDSON SOFT/TAKAR © Aoki Takao•BB2Project• TM & © ABC Family Worl