

Busy Box[®]




Attachment Instructions

1: Remove buckles and straps from polybag.


ATTACH THE TOP STRAPS FIRST (STEPS 2-5)

STEP 2: Thread one strap through each slot on top of Busy Box.


STEP 3: Place Busy Box inside crib against crib rail, with front of box facing inside the crib.



STEP 4: Pull ends of one strap around crib rail until even. Slide strap ends together through buckle end slot CLOSEST TO INSIDE OF CRIB. Slide buckle down strap until it sits on top of crib rail. (ILL. 1) Then, weave strap ends down through middle slot in buckle, (ILL. 2) up through the other end slot in buckle and pull tightly as shown. (ILL. 3)



STEP 5: Slide Busy Box so that a vertical crib bar is between the two bottom slots on back of Busy Box as shown. (ILL. 4) Repeat STEP 4 for other slot on top of Busy Box.




ATTACH THE BOTTOM STRAPS (STEP 6, 7)

STEP 6: Take the remaining strap and thread it through one of the bottom slots on Busy Box toward the inside of crib. Thread strap through the other bottom slot and out of crib as shown. Pull strap ends around crib bar until they're even. (ILL.5)

STEP 7: Using the remaining buckle, slide the two strap ends together through one end slot in buckle. Slide buckle down strap until it sits against crib bar. Weave strap ends down through the middle slot, up through other end slot and pull tight. (ILL. 1-3)

STEP 8: Pull both sets of strap ends from top of Busy Box down so that buckles and strap ends are outside of crib and out of baby's way. (ILL. 6)



WARNING: KEEP STRAP ENDS ON OUTSIDE OF CRIB AND AWAY FROM BABY'S REACH.