



Remove all pieces from plastic bags and discard bags **IMMEDIATELY**.


Assembly



Snap bar on lighthouse cap into hinge on lighthouse. Swing lighthouse cap down and press it into lighthouse.




With back of lighthouse facing you, place small holes on square end of strap over posts on back of toy. Make sure round end of strap extends up toward top of toy. Pull strap upward and move it back and forth so that posts lock over holes.




With back of lighthouse still facing you, pull round end of strap straight up. Insert post on suction cup into hole in strap.

Attaching Busy Bubble Maker to Tub




Wet suction cups on back of toy, and press onto inside of tub. Drape strap over rim of tub and attach suction cup on strap onto outside of tub. Please note: Suction cups attach best to smooth surfaces.




Hang scooper boat and bubble net on the piers. Place turtle in turtle pond.



Making Bubbles



Lift lighthouse cap.



Fill scooper boat with shampoo to the fill line. Pour the shampoo into the lighthouse. Replace cap on lighthouse.



To make bubbles come from the lighthouse, move the handle all the way up and all the way down, in a pumping motion. For best results, pump the handle at a steady, moderate pace.

For Best Results:

- **IMPORTANT:** The handle must be pumped at a steady pace from its highest position all the way down to its lowest position. If your Busy Bubble Maker is not producing bubbles consistently, make sure the bubble wand inside the toy is completely covered by shampoo when the handle is in its highest position. If the handle is in its highest position and the wand is **NOT** covered by shampoo, add more shampoo.
- Use only regular baby shampoo, as it is gentler for children's eyes. **DO NOT** use bubble solutions. **DO NOT** use "gentle conditioning formulas" or baby bath solutions.
- If shampoo leaks from the unit, make sure the unit is level and the strap is tight. Shampoo will also leak if the unit is overfilled.
- After bathtime, rinse Busy Bubble Maker completely. Open lighthouse cap, empty shampoo and run warm tap water through lighthouse. Allow toy to drain before storing.