





Instructions

TANNING FEATURES

In order to tan, Cabbage Patch Kids® Splash 'N Tan Kids™ must be **OUTSIDE** in **direct daylight/sunlight** (a cloudy day will generally work as well as a sunny day). Splash 'N Tan Kids will remain tanned for as long as they are left in the direct daylight. Once removed from full daylight, their tan will fade in about 30 seconds.

(Note: Tanning features will not work in shaded area, even if outside.)



DRAINING FEATURES:

Splash 'N Tan Kids may be fully immersed in water. Their hair is washable and combable, and their bodies are equipped with 4 drain holes to prevent water retention. These drain holes are located in the back of the head, between the legs and on the bottoms of both feet. Excess water may be drained by holding upright and squeezing the body or the legs.

ADDITIONAL INFORMATION:

The head, arms, and legs of the Splash 'N Tan Kids are all completely moveable (360 degrees) and poseable. While the parts are all securely attached to the body, it is possible that your child could accidentally remove them during play. If this occurs, the joints are equipped with a snap feature for re-assembly; re-insert, then press firmly until you hear a click.

WARNING: To ensure the full life expectancy of your Splash 'N Tan Kid, do not leave it outdoors for extended periods of time. When not in use, keep your 'KID' inside and away from direct sunlight. Do not apply sunscreens or other lotions to Splash 'N Tan Kids, as it may hinder their tanning performance.