


Instructions



HOW TO INSTALL BATTERIES:



Battery installation requires a Phillips" screwdriver (not included). Use the screwdriver to remove the screw that secures the battery compartment cover, located on bottom of machine. (Illus A).

Remove the battery door and insert 3 "D" batteries as shown. (Illus. B). Replace the battery door and re-fasten it with the screwdriver.

CAUTION: TO AVOID BATTERY LEAKAGE

- 1.Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions.
- Never mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
- 3. Always remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is stored for a long period of time.





WASHING MACHINE INSTRUCTIONS:

- 1. Place Washing Machine on a solid, flat surface.
- 2. Put <u>1 or 2</u> articles of CABBAGE PATCH KIDS* clothing in the Washing Machine, then fill the machine with water to the indicated line. **Do not overfill**. For best results, wash no more than 2 articles at a time.
- 3. Close the top window door. Turn the on/off switch on, and watch the clothes swish around through the window!
- 4. The machine will continue running until manually turned off.

TO PARENTS: HOW TO DRAIN WASHING MACHINE:

- 1. Take machine to a sink or bathtub. Unhook and extend the back drain hose, then open the end cap as shown. (Illus. A). Water will drain out completely with no further assistance; it is not necessary to tilt or turn the machine.
- 2. After all water is drained, re-hook the hose as shown. (Illus. B). Except when draining, hose should always be on hook, in upright position.

NOTE: Baby shampoo or dishwashing soap can be used with this machine. However, we recommend that you use water only, because of the possibility of eye irritation or ingestion by the child with the use of soap or shampoo. If you do use soap, always rinse the inside of machine thoroughly after each use.

©1992 ORIGINAL APPALACHIAN ARTWORKS, INC. ALL RIGHTS RESERVED. MADE UNDER LICENSE FROM ORIGINAL APPALACHIAN ARTWORKS, INC. Manufactured for Hasbro, Inc., Pawtucket, RI 02862 USA. Made in China. 33540 P/N 43366600

