



# Cut-It-Out!™

## INSTRUCTIONS

### Magical Cutting Tool

**CAUTION:** Contains a functional component with a sharp point. Handle with care.

#### BATTERY DIRECTIONS:






Battery installation requires a Phillips® screwdriver (not included). Turn CUT IT OUT!™ over and locate the battery compartment in the upper right-hand corner. Insert 1 "D" battery as shown, following direction indicators inside compartment.

Take the battery door, which is packaged separately, and fit door onto compartment as shown, locking the tabs in place. Use the screwdriver to tighten the screw and secure the door.

**CAUTION: TO AVOID BATTERY LEAKAGE**

1. Be sure to insert the battery correctly and always follow the toy and battery manufacturers' instructions.
2. Always remove exhausted or dead battery from the product.
3. Remove battery if product is stored for a long period of time.

#### PLAY INSTRUCTIONS:



Take one of the project sheets included in the set and place it on the cutting surface of your CUT IT OUT!™ Magical Cutting Tool. **Do not use CUT IT OUT! on any other surface.** You may tuck the corners of the paper inside the paper stop guides, but do not have to.

Place the cutting guide over the point where you want to start cutting. Turn switch to the "ON" position and insert tip of cutter into the guide as shown to start cutting. The guide will help you make straight, clean cuts, but after some practice you'll be able to do it on your own! If you choose not to use the guide, remember to hold the cutter upright for best results. Cut out the figures on the project sheets, following the lines and starting with the sheets marked for "BEGINNERS." Before long, you'll be an expert!

When you are finished playing, turn switch to the "OFF" position. The cutting guide fits into the slot above the cutting surface. The cutter can be placed inside the guide, or placed in its slot above the cutting surface as shown.

CUT IT OUT!™ also cuts newspapers, magazines and most kinds of paper, so the play possibilities are endless! **(Note: The cutter will not cut cardboard or paper of exceptionally heavy stock.)**