


"Fluffy" my come here puppy!


PUSH DOWN




1. Turn your puppy over and find the battery door. Press down on the battery compartment door as you slide the tab in the direction of the arrow until the battery compartment door is cleared and you can remove the door.

2. Insert three "C" alkaline batteries in the position shown.


POSITION AS SHOWN



CAUTION: To avoid battery leakage, (1) Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instructions. (2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable batteries. (3) Always remove exhausted or dead batteries from the product.




3. Replace the battery compartment door by inserting the one side into place first as shown then lowering the other side. Make sure the tab is not blocking the door as you lower it into place.




4. Press down on the battery compartment door as you slide the tab back to hold the compartment door in place.


PUSH DOWN



5. Place the collar around the puppy's neck. It has a self-gripping fastener.




6. Anytime you want, you can brush your puppy's hair with the included brush. If she gets dirty, surface wash her using only a damp cloth or sponge. **NEVER SUBMERSE YOUR PUPPY IN WATER.** Brushing your puppy after she has been surface washed will help the hair look better.



GETTING READY TO PLAY

Press the ON/OFF button located on the battery compartment. Place the puppy on a level smooth surface. (Highly polished floors or deep pile carpets are not recommended for best performance.) Your puppy will bark and wag its tail.



ARF!
ARF!



WALKING

Now clap your hands or call the puppy and it will raise its left ear, then walk forward in a straight line for a short distance. It stops, wags its tail and waits for another command. (If no command is given in approximately 12 seconds, the puppy will whimper and wag its tail. It will do this **four times** before turning itself off. Once it has turned itself off, you will have to press the ON/OFF button to start again.)



FEEDING

When you are ready, you can feed your puppy a bone. Simply put the bone that comes with your puppy all the way into its mouth, while holding your puppy still. Your puppy will make a crunching sound and wag its tail (for about a minute) as you hold the bone in its mouth. After you take the bone away, the puppy barks and wags its tail. (If no command is given in approximately 12 seconds, the puppy will whimper and wag its tail. It will do this **four times** before turning itself off. Once it has turned itself off, you will have to press the ON/OFF button to start again.)

