




Quick Start Furby Instructions



Before you play with me, please follow these simple steps

- 1.** Turn me upside down and open my battery door.
- 2.** Insert four (4) AA batteries into my battery compartment. Please close the battery compartment.
- 3.** While holding me upside down, put your finger in my mouth and hold down my tongue switch.
- 4.** While holding my tongue switch, please press my reset button.
- 5.** I will now wake up and tell you my name. I am now ready to play.

For more information about installing my batteries, and all the other fun things I can do, please carefully read my instruction book.



Furby™

