

CARE GUIDE





Product and colors may vary.
© 2005 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.

U.S. Pat. Nos. 6811461, 6773327 and Patents Pending.

75801/75798 Asst.

P/N 650150000

* * + * * + * * + * *



Register your chimp's name at:
www.furrealfriends.com/register

The loveable, cuddly chimp that "comes alive"



Thank you for purchasing the FURREAL FRIENDS CUDDLE CHIMP toy, the chimpanzee that moves and sounds like a REAL chimp!

Requires 3 x 1.5V "C" or LR14 size alkaline batteries (not included). Phillips/cross head screwdriver (not included) needed to insert batteries.

CUDDLE CHIMP is the loveable, huggable baby chimpanzee that just adores being cuddled! He can reach out to give you a hug and loves to clap his hands when he's happy. Watch his facial expressions change and listen to him make realistic baby chimp sounds. Pet the soft fur on his back while you're cuddling him and be sure to "feed" him his banana bottle when he gets hungry!

Be sure to take good care of your CUDDLE CHIMP by following the instructions in this booklet!

To begin playing with your CUDDLE CHIMP you must first install batteries.

TO INSTALL BATTERIES

Pull back the plush flap on the bottom of CUDDLE CHIMP. Use a Phillips/cross head screwdriver to loosen screw in battery compartment cover (screw stays attached to cover) on the bottom. Insert 3 x 1.5V "C" or LR14 size alkaline batteries (not included), Replace cover and tighten screw.

NOTE: Your CUDDLE CHIMP will automatically go to sleep when the batteries are inserted. You can wake up your CUDDLE CHIMP by changing the ON/OFF switch to "ON."



CAUTION: TO AVOID BATTERY LEAKAGE

- 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions:
- 2. Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries:
- 3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.




!\ CAUTION:

- 1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markinas.
- 2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short circuit the supply terminals.
- 6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- 7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging, Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

GETTING STARTED

FURREAL FRIENDS CUDDLE CHIMP consists of the following parts:



Your CUDDLE CHIMP makes a variety of realistic chimpanzee sounds and can really:

Yawn Hiccup

• Grunt · Sigh

·Laugh ·Snore

· "oo-ee-ah-ah-ah"

HOW TO PLAY WITH YOUR CUDDLE CHIMP

To turn your CUDDLE CHIMP ON, pull back the plush flap over the battery door and switch the ON/OFF switch to ON. Then replace the flap.



Once your CUDDLE CHIMP is turned on, he will yawn, stretch and then wake up. He is now ready to play with you!

NOTE: Your CUDDLE CHIMP will go to sleep and shut down if he is not played with for 3-5 minutes. You can wake him up by petting his back, "feeding" him, or squeezing his left foot. Please remember to

turn the ON/OFF switch to the OFF position when you are not playing with your CUDDLE CHIMP, in order to conserve battery life.

To start playing with your CUDDLE CHIMP, pet his back, press his left foot or "feed" him with his banana bottle.



Pet his back



Press his left foot



"Feed" him with his banana bottle

Your FURREAL FRIENDS CUDDLE CHIMP is just like a real chimpanzee in many ways. The following illustrations show how you can play with your CUDDLE CHIMP.

"FEEDING"

Your CUDDLE CHIMP comes with a banana bottle specially designed for "feeding." When you hear your CUDDLE CHIMP begin to make sniffing noises, you know it's time for him to eat! Place the end of the banana bottle into his mouth and listen as he slurps it up! You can also "feed" him whenever you want by placing the bottle in his mouth. If you stop "feeding" him and he still wants more, he will cry out! But watch out - if you pet his back after

"feeding" him, he may have a surprise burp in store for you!

If you don't play with your CUDDLE CHIMP after you "feed" him, he may get the hiccups!

CUDDLING & HUGGING

Your CUDDLE CHIMP loves to be cuddled and loves to hug you! Simply press his left foot for five seconds and he will give you a hug! Sometimes he will ask you for a hug automatically by stretching his arms out to you. Be sure to hug him tight and press his back sensor so he will hug you back.



PETTING

Petting your CUDDLE CHIMP on the back relaxes him and lulls him to sleep. You will hear him yown - that means he is getting sleepy. Simply press down on his back for 5 seconds to lull him to sleep but be alert - CUDDLE CHIMP loves to snore!

CLAPPING

CUDDLE CHIMP loves to clap his hands together when he's happy or excited! Wait for him to put his hands together and then gently squeeze his left foot within 5 seconds. Watch as he happily claps his hands!



TICKLING

Your CUDDLE CHIMP loves to be tickled! Touch his left foot and he will giggle for 5 seconds!

CLEANING INSTRUCTIONS

To clean the fur on your CUDDLE CHIMP, gently brush him with a cloth or soft brush to loosen any dirt. Then use a slightly damp cloth to remove stains.

- DO NOT PUT IN THE WASHING MACHINE
- DO NOT SUBMERGE IN WATER
- DO NOT GET WET EXCEPT A DAMP CLOTH ON THE FUR
- TO PREVENT STAINING THE FUR, WIPE DIRT OFF IMMEDIATELY
- IF CUDDLE CHIMP GETS WET, REMOVE THE BATTERIES AND DRY THE FUR
- ONCE COMPLETELY DRY, REPLACE THE BATTERIES
- DO NOT USE DETERGENT OR STAIN REMOVERS ON THE FUR



High temperature will destroy the unit. Do not leave unit in direct sunlight.

- Prevent spills of food and beverage on the unit.
- Do not throw or kick the product, and do not push sharp objects through the speaker openings.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no auarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.