


COBRA C.A.T. II

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Consult the dealer or an experienced radio/TV technician for help.





Product and colors may vary.
© 2003 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office

gijoe.com FOR NEW PRODUCTS AND OFFERS



COBRA C.A.T. II™

Some assembly required.


Requires 2 x 1.5v "D"/LR20 batteries (not included). Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to insert batteries. See instructions.



Not for children under 3 years.



Hair entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required.



Place tank on side. Use a Phillips/crosshead screwdriver (not included) to loosen screw securing battery compartment door, and remove door (screw remains attached to door). Remove and discard batteries. Insert 2 x 1.5v "D"/LR20 alkaline batteries. To assure proper power supply to the motor, gently bend silver battery contacts of battery box cover so they make firmer contact with batteries. Replace battery door and tighten screw with screwdriver. See diagrams.

! CAUTION: TO AVOID BATTERY LEAKAGE

- 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- Do not mix old and new batteries or alkaline, standard (carbonzinc) or rechargeable (nickel-cadmium) batteries;
- 3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.



CAUTION:

- Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- 2. Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.

CANNON

Pull battle cannon from cannon housing.


- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short-circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment.Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.

FIGURE Place figure in command turret. Slide gun into place. GUN

OPERATION


The small command turret is the ON/OFF switch.

- · Move turret forward to turn tank on and go forward.
- · Move turret backward to go in reverse.
- . Turn turret left or right to turn tank left or right.
- To turn tank off, make sure turret is in center position between forward and reverse.









SMALL COMMAND TURRET ON-OFF SWITCH

NOTE: If the vehicle hits a wall or obstacle too big to maneuver over, remove it from the wall or obstacle as quickly as possible to help extend battery life. As the batteries wear down, the clutch mechanism is the first to be affected and the tank will appear to stall. This is an indication that the batteries need to be replaced.

IMPORTANT: Water is the natural enemy of all battery operated toys. Do not play with your vehicle in water, puddles or wet mud.