



# Glitterator™

You can glitter greater with  
the GLITTERATOR.

## INSTRUCTIONS




**1**  
**INSERT BATTERIES**  
To insert batteries in the GLITTERATOR turn the unit upside down. Slide open the battery door.

**2**  
Insert 2 x 1.5 volts "C"/LR14 batteries according to diagram on the inside of the compartment. Close battery compartment door.  
(Do not mix old and new batteries. Do not mix alkaline, standard or rechargeables batteries.)

**3**  
Turn unit right side up and select three different colors of glitter. Place the glitter in the three drawers provided. You can use separate colors in each drawer or mix them up depending on how you want to decorate your item.


**PLEASE NOTE:** When changing the batteries, you need to be sure all drawers are removed from the unit BEFORE turning the unit upside down. If do not remove the drawers the glitter may fall out of the drawers.

4



Place one of the drawers filled with glitter into the slot above the activation button. Be sure the drawer is closed tightly. This will ensure that the glitter will not spill. Also, if the drawer is not securely in place the activation button will not work properly.

5




Select one of the different accessories to decorate or pick something of your own. It's your choice! Use the glue bottle to apply the glue to the area of the accessory you would like to glitterize. The applicator is built-in the top of the glue for easy application. Wherever you apply the glue the glitter will stick.

6



Place your glued object on the heart-shaped grid and place the dome lid on and close tightly. Be sure the dome lid is completely closed. The unit will not work if the dome lid is NOT securely in place.

7



Press the jeweled activation button on the front of the unit. The glitter will circulate under the dome and decorate your glued item. You only need to push the activation as long as is needed to decorate your item. Please note when you release the activation button the circulating glitter will fall back into the drawer.

8

You can change the drawers to mix up all the different colors of glitter on your items. Be as creative as you want when glitterizing.

9

If you have problems with your unit, please check the batteries. Be sure to use fresh alkaline batteries. If the unit still is not working properly, remove all the drawers and carefully turn the unit over on a sheet of newspaper and gently pat the unit to remove any access glitter in the unit around the fan. Then try the activation button again.

#### CAUTION:

Product contains glitter and rings which are small parts and not recommended for children under 3 years old.

### 90-Day Limited Warranty

Tiger Electronics warrants to the original consumer purchaser of the Glitterator Main Unit will be free of defects in material or workmanship for 90 days from date of purchase.

During this 90-day warranty period the unit will either be repaired or it will be replaced (at our option) without charge to the purchaser, when returned either to the dealer with proof of purchase, or when returned prepaid and insured with proof of date of purchase, to Tiger Electronics, 980 Woodlands Parkway, Vernon Hills, Illinois 60061, USA.

Units returned without proof of the date of purchase, or units returned after the 90-day warranty period has expired, will be repaired or replaced (at our option) for a service charge of US\$13.00. Payment must be made by check or money order. This non-warranty service will only be available for one year from the date of purchase. All non-warranty units must be returned postage paid and insured to Tiger Electronics Repair Center, 980 Woodlands Parkway, Vernon Hills, Illinois 60061, USA.

Tiger Electronics will not be liable for loss of use of the product or other incidental or consequential costs, expenses, or damages incurred by the purchaser. Any implied warranties are limited in duration to the 90-day period from the original date of purchase.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state so the foregoing limitations may not

apply to you. This warranty does not cover damages resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship.

HOW TO GET SERVICE FROM THE TIGER ELECTRONICS REPAIR CENTER ON YOUR ELECTRONIC TOY DURING AND AFTER THE 90-DAY WARRANTY PERIOD.

During the 90-day warranty period, you may have a defective toy replaced at the dealer from which it was purchased. If however, during the 90-day warranty period, you choose to obtain repair or replacement from the Tiger Electronics Repair Center, please make the arrangements described below:

1. Pack the toy carefully in the original box. If the box is not available, use a good carton with plenty of newspaper, styrofoam or other padding all around and tie it securely.
2. Carefully print on the box or carton the following name and address:  
TIGER ELECTRONICS REPAIR CENTER  
980 Woodlands Parkway  
Vernon Hills, Illinois 60061, USA  
Also, don't forget to include your return address.

3. Put parcel post stamps on the package; insure the package, then mail.

After the 90-day warranty period and up to one year from the date of purchase, do all of the above PLUS enclose you check or money order for US\$13.00 as payment for the repair service.