



6910 and 6911

## INSTRUCTIONS


Requires 4 "C" alkaline batteries, not included.

Ages: 3 and up


**PARENTS: PLEASE CUT PLASTIC FASTENING MATERIALS AND DISCARD.**

**CAUTION:** Includes toy pacifier not to be used as a real pacifier. Not intended for infants.


## TO INSTALL BATTERIES



1. Open seam at back of doll to expose battery cover.



2. Remove screw with a Phillips screw driver. Remove battery cover.



3. Install 4 "C" alkaline batteries as shown. Do not use nickel cadmium batteries. Replace battery cover and fasten outfit.




4. To test function remove pacifier — doll will start to cry. When pacifier is replaced the doll will stop crying. Note: To activate

Hush Little Baby™ the pacifier must be placed in the mouth and then removed.

5. When batteries become weak, one or more of the doll's functions may operate in an irregular fashion. When this occurs, insert a fresh set of batteries.

## SHE MOVES AND SOUNDS LIKE A REAL BABY



- Remove HUSH LITTLE BABY™'s pacifier to make her cry.
- To stop her crying, feed her the bottle. She makes sucking sounds and her mouth, cheeks and eyes move when you feed her the bottle.
- She coos approximately 4 seconds after the bottle is removed from her mouth. The cooing lasts approximately 10 seconds, followed by 4 seconds of silence, then the crying resumes.
- After 40 seconds of continuous uninterrupted crying, HUSH LITTLE BABY™ will automatically shut herself off. To reactivate her crying, insert and remove her pacifier.

## TO TURN HUSH LITTLE BABY™ OFF

- HUSH LITTLE BABY™ can be turned off by inserting the pacifier in her mouth.
- She will automatically shut herself off after about 40 seconds of continuous uninterrupted crying. To reactivate her crying, insert and remove pacifier.

## CARING FOR HUSH LITTLE BABY™

- Because HUSH LITTLE BABY™ uses batteries, never put her in water! If she gets dirty, simply wipe her off with a damp cloth and a non-abrasive soap.
- Remove the batteries if you do not intend to play with HUSH LITTLE BABY™ for an extended period of time.
- HUSH LITTLE BABY™'s outfit can be machine washed; gentle cycle, tumble dry cool. Remove pacifier from ribbon before washing outfit.

# LIMITED WARRANTY

**Important:** Please check batteries. When batteries become weak, one or more of the doll's functions may operate in an irregular fashion. When this occurs, insert a fresh set of batteries.

**What is Covered.** Tonka Corporation warrants to the original retail purchaser of its HUSH LITTLE BABY™ doll that the product is free from defects in materials or workmanship.

**How Long the Coverage Lasts.** The warranty covers the period of 90 days after the date of purchase.

**What We Will Do.** We will repair or replace the product (at our option) free of charge if a defect is discovered within the warranty period, subject to verification of the defect or malfunction and the date of purchase.

**How to Get Help.** Allow us the opportunity to help you. Please do not return the product to the store where it was purchased. We want to satisfy you whenever you buy a Tonka product. For fast assistance, call our TOLL-FREE CONSUMER AFFAIRS NUMBER:

**1-800-347-3628 from 8:00 to 4:30 Monday through Friday.**

**Obtaining Warranty Service.** If the product requires warranty service, send it postage prepaid, along with your name, address, telephone number, a brief description of the problem, and a copy of the dated sales receipt with the purchase price circled, to:

**Tonka Corporation**  
c/o Kenner Products  
2950 Robertson Avenue  
Cincinnati, OH 45209

Be sure to pack the product securely in its original box and packing materials, or in a sturdy container with plenty of protective padding. We recommend that you insure the parcel for its full retail value.

**Service After the Warranty Period.** If the product requires service after the warranty period, call the Toll-Free Consumer Affairs number listed above. Our representatives can help you with your questions.

**What is Not Covered.** This warranty does not apply to defects arising from abuse, alteration or unreasonable use of the product. Any applicable implied warranty, including warranties of merchantability and fitness, are hereby limited to 90 days from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable expressed or implied warranties are hereby excluded. Some states do not allow limitations on how long implied warranties last and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

**Your Legal Rights.** This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state.

Printed in U.S.A. Part No. 467508  
The trademark HUSH LITTLE BABY is owned by Irwin Toy Limited.