


WHIRL AROUND PLAYGROUND™




TO ASSEMBLE ...




Press elevator into place on side of playhouse.




Snap playhouse onto playset base, as shown.



Hook swing seats onto canopy.



Fit slide onto tree house, making sure it is also pressed into place on the base.




Snap tree house onto base as shown.



Press canopy onto the tree house.



Press hammock into place between playhouse and tree house.



Press tunnel and flags into place on playset base.

TO PLAY

Treetop swing set: Wind top clockwise, then place pet in the top seat (make sure print on pet's paw is touching paw print on seat) and let it go. Swings go 'round and 'round!

Turn top of the merry-go-round to make it spin! Slide lever to race pet through the obstacle course!

© 2004 Hasbro. All Rights Reserved. TM & ® denote Reg. U.S. Pat. & TM Office.

NAME YOUR PETS
& PLAY ONLINE AT
LITTLESTPETSHOP.COM