FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FILLING: ALL NEW MATERIALS: 100% POLYESTER FIBER

REG. NO. PA-282

Questions? Call 1-800-752-9755 Thank you for choosing Babblin' Boo, the lovable friend from Disney and Pixar's Monsters, Inc.!


⚠ WARNING:

CHOKING HAZARD - Small parts. Not for children under 3 years.

Ages 3 & Up 3808

Babblin' Boo With magical Little Mikey

Includes 2 "AA" batteries. Phillips screwdriver (not included) needed to replace batteries.




© Disney/Pixar

*® & © 2001 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
3808 P/N 6085840000.

Playtime

Babblin' Boo and her friend, Little Mikey, are cuddly pals who love to play!

- Press Babblin' Boo's tummy to hear her giggle and babble!
- Make Babblin' Boo squeal and laugh. Hold Little Mikey up to Boo so that his nose touches her shirt, as shown (1). Take Little Mikey away to hear Boo squeal (2). Put Little Mikey back up to Boo to hear her laugh (3).




То СІєви

Babblin' Boo and Little Mikey are surface washable only.

To Replace Batteries

Lift shirt on back of Babblin' Boo to access battery compartment. Use a Phillips screwdriver to loosen screw in battery compartment door (screw remains attached to door). Remove door. Remove old batteries. Insert 2 fresh "AA" alkaline batteries. Replace door and tighten screw.



CAUTION: TO AVOID BATTERY LEAKAGE

- Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- Always remove weak or dead batteries from the product.