

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

AGES 3+

6315

# Soft Talking Sulley with Boo

Thank you for choosing Soft Talking Sulley with Boo, two lovable characters from Disney and Pixar's Monsters, Inc.!

Includes 2 "AA"/LR6 batteries. Phillips screwdriver (not included) needed to replace batteries.



Disney PIXAR  
**MONSTERS, INC.**



## Playtime

**Soft Talking Sulley with Boo is a special nighttime companion who talks!**

- Squeeze Sulley's right hand for comforting phrases!
- Bend Boo's arms and legs into lots of poses!




## To Clean

Soft Talking Sulley and posable Boo are surface washable only.

## To Replace Batteries

Open back of toy to access battery compartment. Use a Phillips screwdriver to loosen screw in battery compartment door (screw remains attached to door). Remove door. Insert 2 fresh "AA" alkaline batteries. Replace door and tighten screw.

Close seam.



## ⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3) Always remove weak or dead batteries from the product.