


WARNING:
 CHOKING HAZARD - Small parts.
 Not for children under 3 years.




CONTAINS: Figure, Two Pontoon Assemblies, Deck, Left and Right Hulls, Two Hull Wheels, Two Pontoon Wheels, Two Battle Decks, Hatch Cover, Main Sail, Rear Sail, Steering Wheel Assembly, Mast, Two Rope Ladders, Harpoon Reel, Harpoon, Launcher and Label Sheet.

**DRAGON WING™
 OFFICIAL SPECIFICATIONS**

- 1. **CRYSTAL MAIN SAIL**
- 2. **REAR STEERING SAIL**
- 3. **SHOOTING SORCERER CANNON**
- 4. **BATTLE HARPOON HARPOON REEL**
- 5. **HIDDEN ROLLING WHEELS**
- 6. **STABILIZING PONTOON**
- 7. **ROPE LADDERS (2)**
- 8. **SIDE BATTLE DECKS (2)**
- 9. **FOLDING SHIP'S WHEEL**




Remove all pieces from plastic frames. If you have difficulty use safety scissors.
CAUTION: Do not point weapon at eyes or face.




MAIN SAIL ASSEMBLY
 16. Carefully slide the main (large) sail onto mast and over posts (inset). Fit boom into sail as shown, then snap boom into mast.

MAST INSTALLATION
 15. Slide base of mast into holder on deck.




PEEL AND APPLY LABELS AS SHOWN.


Product and colors may vary.
 Approximate size of vehicle is 21" (53 cm) L X 8" (20 cm) W X 12" (30cm) H.
 ©1994 Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.
MADE IN USA. FIGURE MADE IN CHINA. Unauthorized Duplication Is Strictly Prohibited.
 ©1992 MORTAL KOMBAT™ is a trademark of Midway® Manufacturing Company. All Rights Reserved. Used Under License. 81348 P/N 45702700



SHOOTING HARPOON
 14. Thread other end of string through hole in harpoon and tie a knot in the end. Insert harpoon into cannon. Press trigger to fire. **CAUTION: Do not aim weapon at eyes or face.**



HARPOON REEL ASSEMBLY CONT.
 13. Snap reel into slot at front of hull as shown.



ROPE LADDER INSTALLATION
 17. With sail (not shown) hook bottom of rope ladder into hole on left railing as shown. Fit hole at top of rope ladder over post at top of mast. Repeat with other rope ladder on right railing.




FIGURE INSTRUCTIONS
 18. Lift right arm counterclockwise as shown, then hold in place. To activate, release arm.