


# NEW KIDS ON THE BLOCK™

AM/FM


# RADIO

## Instructions

### BATTERY INSTALLATION



1. With front of radio facing up and bottom of radio facing you, press down tabs and pull cover off radio.




2. Insert 4 "AA" batteries into battery compartment as shown inside battery compartment and in illustration. Replace cover. (Alkaline batteries are recommended.)

### CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturer's instructions.
2. Never mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Always remove exhausted or dead batteries from the product.

### FEATURES



● **Tuning Knob:**  
Turn knob left or right to select a station.

● **Telescopic Antenna:**  
Extend and adjust it for better station reception.

● **Carry Handle:**  
Handle adjusts for carrying or storing radio.

● **Band Selector Switch:**  
Slide it to either AM or FM position.

● **Volume/On-Off Control:**  
Turn switch right to turn on radio. Turn switch left or right to adjust volume. Turn switch left until you hear a click to turn off radio.

● **Earphone Jack:**  
Plug in earphones (not included) for private listening.

REAR