


MAXX FORCE


NERF TO THE NEXT POWER!TM

WHIPTAIL SCORPION

Blaster




1
Apply Label to body.




ONE-TIME ASSEMBLY
Once assembled, cannot be taken apart!

2
Insert the post on front of the body into the pinchers.




3
Place tail into the notch in the bottom of the body. Once tab is fully inserted, pull tail in the direction of arrow to lock it in place.




Tube fits into slots


4
Carefully snap tube into holders along the tail as shown.



5 Snap legs onto body sides. Insert rear tab of legs first, then proceed to insert rest of pegs to attach legs.



6 Load a dart all the way onto the launching tube. Store the other two darts in the holders as shown.



7 Pull the pinchers out until they lock in the "ready" position for firing.



8 As you pull the trigger, the tail will curl up and point forward. Aim at your target, then continue to squeeze the trigger, firing the dart.