




Switchfire™ Blaster


100416



The only NERF® action toy that lets you fire two different types of ammo at your will! Choose your firepower...then nail your target each time you pull the handle all the way back and push it quickly all the way forward.


SEE OTHER SIDE FOR COMPLETE INSTRUCTIONS!

Kenner®
©1994 Kenner, a division of Tonka Corporation, Cincinnati, Ohio 45202 51176800




LABELS


1. Apply labels to both sides of toy in positions shown.




2. Attach ball-blasting barrel or missile launcher attachment to the base unit by inserting attachment's tabs all the way into the slots in the base unit, then turning the attachment in the direction of the arrow shown.



Depending on which attachment is inserted into the base unit, load a missile all the way onto the launching tube or up to three balls into the barrel. Pull base unit's handle all the way back, then push it quickly forward to fire a missile or a ball.



BALL BARREL



MISSILE STORAGE POSITION

4. Fit both attachments together by sliding the ball barrel onto the missile launcher as shown. Then either attachment can be attached to the base unit and fired. Missiles can be stored on the missile launcher.