

## NERF BOOMERANG FLYING INSTRUCTIONS

The success of flying your NERF BOOMERANG is dependent upon several factors, one being the wind current, the other being tuning technique. Below are some hints that may help you!

<u>TUNING</u>	<u>THROW TECHNIQUE</u>	<u>RESULT</u>
Slightly bend each wing upward.	Hold vertically, snap wrist, gentle throw.	Spin around and return.
Twist each wing to the left.	Hold flat, gentle throw.	Boomerang flies in a smaller circle.
Twist each wing to the right.	Hold flat, gentle throw.	Boomerang will fly farther.

Please keep the following factors in mind when using your NERF BOOMERANG.

- Because the Boomerang is made of soft foam, the tuning adjustments you make may need to be repeated for each throw.
- You will get best results with a wrist snap and gentle throw.

If you have further questions regarding your NERF BOOMERANG, please feel free to contact us.

In Massachusetts: 1-800-892-1297

All other states: 1-800-225-0540