

NERF®

AGES 6+

61496

PLAY YOUR GAME™


Nite Finder™

Thank you for purchasing the NERF NITE FINDER,
the NERF blaster with light beam targeting!

⚠ **CAUTION:** Do not aim at eyes or face.


TO AVOID INJURY: Use only darts designed for this product.
Do not modify darts or dart launcher.

Before playing with your NERF NITE FINDER you must first
install the batteries.



TO INSTALL BATTERIES

Use a Phillips/cross head screwdriver to loosen screw in battery compartment door (screw remains attached to door). Insert 2 x 1.5V "AA"/LR6 alkaline batteries. Replace door and tighten screw.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.



⚠ IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.

⚠ CAUTION:


1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERY.

Nerf® Nite Finder™




Target with stand included.


TO PLAY



1. Pull back handle.




2. Load dart.



3. Press trigger half way down for light beam.
Line up light beam on the target.

NOTE: Light beam lens is adjustable for increased accuracy.



4. Press trigger all the way down to launch the dart.

The **NERF NITE FINDER** blaster takes your blasting to a whole new environment – the **DARK!** Step into the night and bring your **NITE FINDER** blaster with you for some high precision target practice! Line up the red light beam on your target and **READY...AIM...FIRE!** See how your blasting skills measure up, day or night.



© 2003 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
61496 P/N 6305320000

NERF.COM
FOR NEW PRODUCTS AND OFFERS
Questions? Call: 1-800-327-8264