

5716



# Talking Allegra™

## Instructions

Ages 2 & Up



PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE USE.

Thank you for purchasing this toy. If you have any questions or comments about this toy, please call Playskool toll free at 1-800-PLAYSKL.

### HOW TO OPERATE

Talking Allegra is a soft, cuddly friend who says 6 special phrases.

To hear a phrase, simply squeeze or hug her tummy!


Talking Allegra says:




### TO REPLACE BATTERIES

3 "AAA" batteries included. When batteries are exhausted, replace with 3 "AAA" batteries.


Parents: Use a Phillips screwdriver to replace batteries.




- Hold zipper between thumb and index finger, open back of toy and remove sound unit. If difficult, use pliers to hold and pull zipper end.



- With Phillips screwdriver, loosen screw in sound unit cover and remove cover.
- Discard exhausted batteries.



- Insert 3 "AAA" batteries into compartment as indicated.
- Replace cover on sound unit and tighten screw.



- Make sure laces are tied to sound unit. Reinsert sound unit into toy (in an upright position), with button side facing the front of Talking Allegra.

(To help prevent child from tampering with sound unit, the zipper is not equipped with pull tab.)

### **CAUTION:**

1. As with all small batteries, the batteries included with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect.
2. Make sure batteries are inserted correctly and follow the toy and battery manufacturers' instructions.
3. Do not mix old and new batteries.
4. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

After reinserting the sound unit, avoid exposing toy to excessive heat or submersion in water, which could cause damage.

### **HOW TO CARE FOR TALKING ALLEGRA**

- Talking Allegra is machine washable and dryer safe.
- To wash, unzip closure on back of toy, remove sound unit and untie laces from sound unit.
- Place toy in pillow case and tie end closed. Machine wash separately on gentle cycle with cold water and mild detergent. Do not bleach. Tumble dry promptly in pillow case on low heat setting.
- Retie laces to sound unit, by making a shoe knot (double-knot the bow to further prevent child tampering).
- Reinsert sound unit into toy (in an upright position), with button side facing the front of Talking Allegra.

### **IF THERE'S A PROBLEM...**

- If Talking Allegra's voice slows down or becomes scratchy, change the batteries.
- If Talking Allegra doesn't work after batteries are replaced, check to be sure batteries are inserted correctly.
- If you have any questions, comments or problems concerning the operation, care or repair of this product, please call this toll-free number: 1-800-PLAYSKL (1-800-752-9755).

### **FCC STATEMENT**

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Product and colors may vary.

©1995 Viacom International Inc. All Rights Reserved. Nickelodeon and Nick Jr., and all related titles, logos and characters, if any, are trademarks of Viacom International Inc.

PLAYSKOOL® is a trademark of Hasbro, Inc. ©1995 Hasbro, Inc., Pawtucket, RI 02862 USA.

All Rights Reserved.

®denotes Reg. U.S. Pat. & TM Office

**MADE IN CHINA.**