


• Using the pan handler, slide pan into baking chamber until arrow lines up with edge of chute.


NOTE: DO NOT PUT PLASTIC TREAT MOLD IN OVEN. DO NOT LEAVE PAN PUSHER IN OVEN.

• Bake treat for about 5-8 minutes until it is firm




• When treats are finished baking, push pan into the cooling chamber with pan handler. Push all the way up to the "STOP" indicator on the pan handler.

• Cool for 10 minutes in cooling chamber, then use the pan handler to remove from oven.



• When finished baking, unplug Oven.



• Wash pans and utensils in warm, soapy water. Rinse and dry thoroughly.



• Wipe cool oven clean with a damp cloth.
DO NOT immerse oven in water.

Product and colors may vary.

© 2001 Hasbro, Inc., Pawtucket, Rhode Island 02862 USA.

All Rights Reserved. MADE IN CHINA



CAUTION: ELECTRIC TOY:

Immersing this toy can cause an electric shock. Not recommended for children under eight years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.



739G


24589

Ages: 8 & Up

INSTRUCTIONS


Includes:

Bake-A-Treat™ Oven,
2 baking pans, pan
handler, spatula, rolling
stick, 3 cookie
cutter molds,
one 5-ounce
container of
Doggie Dough
Treats™ Bacon flavor



You will also need: 100- Watt Light Bulb Required-Frosted or Standard.
(Do not use soft white or long life.)

For maximum enjoyment of this product, be sure to follow all instructions carefully. If you have any questions, comments, or need additional information concerning this product or its parts, please call our Hasbro Consumer Affairs hotline at 1-800-327-8264, Monday through Friday during business hours (eastern time). Phillips screwdriver required for assembly.





ADULT SUPERVISION RECOMMENDED

HOT pans and food. Handle carefully,

HOT oven interior, oven top and oven back. Do not touch.

WARNING: Shock Hazard. Pull plug out of receptacle before removing back and changing light bulb. Do not use light bulbs greater than 100 watts

ALWAYS: Unplug Oven when not baking. Use Pan Handler tool to move pans through the baking chamber. Allow Oven, Pans and Doggie Dough Treats™ to cool before handling. Wash all utensils before the first use and after subsequent uses.

NEVER use plugged-in Oven around water at any time. Never leave plugged-in Oven unattended or unassembled. Never push Pans through Oven with your fingers. Do not leave empty Pans or Pan Handler in Oven.

DANGER: To prevent electric shock, do not immerse Oven in water. Wipe clean with damp cloth, We recommend that you periodically examine the product for potential hazards and that any potentially hazardous parts be repaired or replaced.



DO NOT use light bulbs of higher wattage, long life or soft white type bulbs. Use 120 Volts A.C. only - 60 Hz 100 watts.

CAUTION: Adult supervision recommended. Internal metal edges. Care should be taken during installation of the light bulb. Phillips screwdriver required (not included).

© 2011 Hasbro, Inc., Pawtucket, Rhode Island, USA
All Rights Reserved. MADE IN CHINA



GETTING THE BAKE-A-TREAT™ OVEN READY TO USE



Install Light Bulb


- Install one regular frosted or standard 100-Watt bulb into socket panel.
- Do not use long life, soft white or high efficiency bulbs, or bulbs of higher wattage or lower wattage, which will cause oven to work improperly.

Remove Back of Oven

- Turn oven so that the back is toward you.
- Using a Phillips screwdriver, remove the six screws from the back panel and lift panel out.

Install Back of Oven

- Replace panel and six screws.




Labels

- Apply labels as shown.
- Fold and place sign on top of Oven.

Protective Coating:


- The pans and metal parts in your oven are coated with a food-grade oil for protection during transit.




- Coating is nontoxic, but for the first few bakings it may detract from the taste of the food if not washed.
- The "new" smell the oven gives off the first few minutes is the protective oil evaporating from the metal parts in the oven. You may also see a vapor. It is nontoxic and evaporates quickly.

HOW TO USE THE BAKE-A-TREAT™ OVEN

- Wash all utensils, pans - and your hands.
- Plug in Oven, preheat for 15 minutes.



- Scoop out Doggie Dough Treats mixture using the spoon end of the spatula tool.



- Roll mixture flat with the rolling stick.



- Using a cookie cutter, mold a doggie treat. Place it on baking pan.

