

## MAKING COOKIES:



Open the oven door and slide out the cookie tray. Place a full scoop of the "Cookie Dough" compound onto any or all of the 4 cookie settings on the tray!



Slide tray back in, and close the oven door. Set the timer, and wait for the bell to ring. Open the door again, and you've made yummy-looking cookies!



Use the spatula to remove the cookies from the tray and put the cookies on the plates as shown.

## DECORATING THE COOKIES:



Now decorate the cookies you've made! Use the Sparkle PLAY-DOH® compound with the cherry chip molds underneath the plate to make pretend cherry chip cookies!



There are more decorative molds on the back of the scoop and spatula, and on the bottom of the other cookie plate.

U.S. Patent Pending.

NONTOXIC CONFORMS TO ASTM D-4236-89  
PLAY-DOH® and PLAY-DOH® logo are registered trademarks of Tonka Corporation identifying quality modeling compound products produced exclusively by Playskool, Inc.

©1993 Tonka Corporation.  
©1993 Playskool, Inc., Pawtucket, RI 02862 USA.  
All Rights Reserved.  
MADE IN USA.

## EXTRUDER:



To make fun cookie tops, slide the shapemaking strip onto the extruder, fill extruder with compound and plunge out shapes as shown, using the knife to trim shapes.

## CLEAN-UP:

DO NOT USE HOT WATER OR CLEANING SOLUTIONS to clean PLAY-DOH® modeling compound from carpets or fabrics. For best results, remove excess and allow compound to dry. Loosen compound with stiff brush and vacuum clean. If necessary, wash with gentle soap, COLD water and brush. Repeat if necessary. For best results, do not mix regular PLAY-DOH® compound with Sparkle PLAY-DOH® compound.

NOTE TO PARENTS: The colorful, harmless glitter that makes our PLAY-DOH® Sparkle may temporarily stick to your child's hands or face during play.

