
BATTERY INSTALLATION

Use a Phillips screwdriver to loosen screw in battery compartment door (screw remains attached to door). Remove door. Insert 2 "AA" alkaline batteries. Replace door and tighten screw.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- 3) Always remove weak or dead batteries from the product.

EASY 3-STEP CLEANUP!

- 1. Place PLAY-DOH® Brand Modeling Compound back in cans and seal lid.
- 2. Remove excess from carpets/fabrics, then allow remaining compound to dry.
- 3. Loosen dried compound with stiff brush and vacuum clean. If necessary, brush with gentle soap and cold water. (Do not use hot water or cleaning solutions to clean PLAY-DOH® compound from carpets/fabrics.)

Easy to Squeeze Play-Doh®...It's our softest ever!
Results vary depending on child's age and level of skill.
NONTOXIC CONFORMS TO ASTM D-4236
PLAY-DOH and PLAY-DOH logo are trademarks identifying quality modeling compound products produced exclusively by Hasbro, Inc.
© 2002 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
17345 P/N 6148040100



Doctor Drill 'n Fill"

Thank you for choosing this fun-filled Play-Doh® brand playset!

Requires 2 "AA" alkaline batteries (not included). Phillips screwdriver required (not included) for battery installation.

