

## EASY 3-STEP CLEANUP!

1. Place PLAY-DOH® Brand Modeling Compound back in cans and seal lid.
2. Remove excess from carpets/fabrics, then allow remaining compound to dry.
3. Loosen dried compound with stiff brush and vacuum clean. If necessary, brush with gentle soap and cold water. (Do not use hot water or cleaning solutions to clean PLAY-DOH® compound from carpets/fabrics.)

Results vary depending on child's age and level of skill.

New Easy to Squeeze Play-Doh®. It's our softest ever!

NONTOXIC CONFORMS TO ASTM D-4236

PLAY-DOH and PLAY-DOH logo are trademarks identifying quality modeling compound products produced exclusively by Hasbro, Inc.

© 2001 Hasbro. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office.

22147 P/N 6069160000



AGES 3+

22147

# Electronic Fuzzy Pumper® Buzz Cuts™

Adult assembly required.

Thank you for choosing this  
fun-filled Play-Doh® brand  
playset!

Requires 2 "AA" alkaline  
batteries (not included).  
Phillips screwdriver (not  
included) required  
for battery  
installation.



