


69795- Light Saber Instructions - loaded on the box - no slip sheet



1 Insert batteries into handle, then screw handle onto light tube collar.

2

When it becomes necessary to replace bulb, unscrew bulb holder out of light tube collar. Take bulb holder apart. Replace bulb. Put bulb holder back together. Return bulb holder to inside of light tube collar.

CAUTION: To avoid battery leakage, (1) Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instructions. (2) Do not mix old and new batteries or alkaline, iodine (carbon-zinc) or rechargeable batteries. (3) Always remove exhausted or dead batteries from the product.