


ATTACK OF THE CLONES

Includes 3 A-76 button cell batteries. Phillips screwdriver needed to change batteries (not included).

## **Stomping Attack!**



### TO REPLACE BATTERIES:

Loosen screw in door with Phillips screwdriver (not included). Remove door. Insert 3 fresh A-76 button cell batteries. Replace door and tighten screw.



# A CAUTION:

- As with all small batteries, the batteries used with this
  toy should be kept away from small children who still put
  things in their mouths. If they are swallowed, promptly
  see a doctor and have the doctor phone (202) 625-3333
  collect.
- Make sure the batteries are inserted correctly and follow the toy and battery manufacturers' instructions.
- Do not mix old and new batteries, alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

#### FCC STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Consult the dealer or an experienced radio/TV technician for help.

Product and colors may vary.

© 2002 Lucasfilm Ltd. & @ or TM where indicated. All rights reserved. Used under authorization.

\*8, \*TM & © 2001 Hasbro. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office.

P/N 6136500000