

# FORCE BATTLERS™ STAR WARS®



**WARNING:**

CHOKING HAZARD—Small parts.  
Not for children under 3 years.

**AGES 4+**


87073/85179 Asst.

Hold lower body. Twist upper body and  
release for whirling lightsaber attack.




## QUICK-CHANGE ACTION! EMPEROR PALPATINE®

Insert Force lightning  
into robe sleeve.




Press  
button to  
launch.



THUMBWHEEL

Turn thumbwheel to change Palpatine's  
face to Force-damaged look.



Remove lightsaber blade to show lightsaber in  
“deactivated” mode. Re-attach blade for “activated” mode.



Some poses may require additional support.

Product and colors may vary.

© 2005 Lucasfilm Ltd. & © or TM where indicated. All Rights Reserved.

®\* and/or TM\* & © 2005 Hasbro. All Rights Reserved.

TM & © denote U.S. Trademarks.

P/N 6532890000

Visit



starwars.hasbro.com

For more toy information visit: [www.starwars.hasbro.com](http://www.starwars.hasbro.com)

TM \*