
AGES 4 AND UP





1 Attach wings to vehicle. Push them down to set. Push button to deploy wings. Push wings down to reset.




Button

2. Slide the rear landing skid onto the launcher.







4. Load the projectile into the launcher. Press down on the button to fire. 5. Open canopy to seat figure in cockpit. 6. Apply labels using the numbers on the label sheet and these illustrations as a guide. 1 1 ø Ø 1 Inside cockpit **Bottom** TM1-3 1997 HASBRO, FIC Mucket, Rhode Island 92862 Pignts Peserced

Back

MADE IN CHINA.

Missill 1997 Ligast micro