

FORCE BATTLERS STAR WARS



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 years.


AGES 4+

85355/85179 Asst.

MULTIPLE LIGHTSABER ATTACK! GENERAL GRIEVOUS





Press button to fire.



Insert grapple hook.



Firmly attach hook to surface. Attach figure's hands to bar. Raise end to make figure slide down string.



Squeeze legs together for multi-arm attack.



Lightsabers attach.



Remove lightsaber blades to show lightsabers in "deactivated" mode. Re-attach blades for "activated" mode.



Some poses may require additional support.
Product and colors may vary.
© 2005 Lucasfilm Ltd. & ® or TM where indicated. All Rights Reserved.
®* and/or TM* & © 2005 Hasbro. All rights reserved.
® denotes Reg. U.S. Pat. & TM Office.

P/N 6449270000



starwars.com

For more toy information visit: www.starwars.hasbro.com