

STAR WARS BATTLE FIGURES STAR WARS



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 years.


AGES 4+

85356/85179 Asst.




SLASHING ATTACK!

DARTH VADER



Attach shield to arm.



Squeeze legs together
for slashing attack.

Remove lightsaber blade to show lightsaber
in "deactivated" mode. Re-attach blade for
"activated" mode.



Some poses may require additional support.
Product and colors may vary.
© 2005 Lucasfilm Ltd. & © or TM where indicated. All Rights Reserved.
®* and/or TM* & © 2005 Hasbro. All rights reserved.
© denotes Reg. U.S. Pat. & TM Office.

For more toy information visit: www.starwars.hasbro.com

P/N 6449280000



starwars.com